

680.310 SOUSVIDE COOKER - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
1	ZCE160-1011	SHELL	1
2	ZCE160-1012	ENTER ASS'Y	1
3	ZCE160-1013	WATERPROOF O-RING F	1
4	ZCE160-1014	O-RING H	2
5	ZCE160-1015	JOINT B	1
6	ZCE160-1016	PANEL LOWER CASE	1
7	ZCE160-1017	CONTROL PCB	1
8	ZCE160-1018	PANEL UPPER CASE	1
9	ZCE160-1019	PANEL	1
10	ZCE160-10110	ELBOW C ASS'Y	1
11	ZCE160-10111	HEATER ASS'Y	1
12	ZCE160-10112	BOTTOM PLATE	1
13	ZCE160-10113	FOOT	4
14	ZCE160-10114	POWER PCB	1
15	ZCE160-10115	WATER PUMP	1
16	ZCE160-10116	DRAIN ASS'Y	1
17	ZCE160-10117	BODY HANDLE	1
18	ZCE160-10118	DETECTOR ASS'Y	1
19	ZCE160-10119	DETECTOR LIN ASS'Y	1

680.310 **SOUSVIDE COOKER** - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
20	ZCE160-10120	POWER CORD	1
21	ZCE160-10121	LINE BASE	1
22	ZCE160-10122	INPUT ASS'Y	1
23	ZCE160-10123	WATERPROOF O-RING B	1
24	ZCE160-10124	WATERPROOF O-RING A	4
25	ZCE160-10125	JOINT A	1
26	ZCE160-10126	HANG	1
27	ZCE160-10127	BOWL ASS'Y	1
28	ZCE160-10128	RISE BRACKET	1
29	ZCE160-10129	FOOD BRACKET	1
30	ZCE160-10130	COVER ASS'Y	1
31	ZCE160-10131	PUMP MOUNT	1
32	ZCE160-10132	WATER PUMP	1
33	ZCE160-10133	PIPE ASS'Y	1
34	ZCE160-10134	PIPE-1.04M	1